



Exiting direction should be used only as a planning tool. If floor exits and building exits have the capacity to accommodate the floor and building design occupant load, and travel distance from each occupied space to an exit complies, it is rare but not a violation of code to have an exterior exit door with insufficient capacity for the design load shown passing through it.

Note: Do not obscure building elements and/or information with wall rating symbol(s).

SAMPLE EXITING DIAGRAM